

End cap

T225-EC-G

Close an open T225 run end where a power feed or adjoining section is not installed. Count the required end caps from the terminations shown on the approved project layout.



End cap with formed housing flanges

CATALOG NUMBER

T225-EC-G

FUNCTION

Closes an open busway end


ORDERING UNIT

Each; sold individually

QUANTITY BASIS

One per required open run end

POSITION + SECURE



01 Position over the open housing end



02 Secure and check the closure

ORDERING + COMPLETION CHECK

Catalog number	Description
T225-EC-G	T225 end cap; each

Verify that all open busway ends are closed and secured before energization. End cap only; other run components are ordered separately. Source: T225 O&M manual, Step 4.

Component of the ETL Listed T225 system, evaluated to UL 857 / CSA C22.2 No. 27; not an individually listed product. Intertek 5011082; Report 106508638CRT-001. [View listing scope and ratings.](#)